master QSG_CKA7740_EURO.qxd 21/12/2007 13:29 Page 1

What's in the box



Wireless Modem Router




Wireless USB adapter




Quick start guide



Power adapter



Installation CDROM



Ethernet cable



Line cord

What else will you need

ADSL filter adapted to your telephone plug



A desktop or a laptop with free USB port




A web browser



An Internet connection

1 Install your wireless modem router

A Insert installation CD




- Insert the installation CD into the PC's CD ROM (or DVDROM) drive

> *The installation program will start automatically*


- Follow instructions on the screen

If for some reason the installation does not start automatically:



- Click on Windows **START** and then **RUN**
- Type **explorer** and navigate to the CD ROM (or DVDROM) drive
- Double-click on **Setup.exe**

B Choose your language




By default, the language of your operating system will be choosen, but you have 10 seconds if you want to select another one.

- Click on the required language

> *The next screen will be displayed automatically*

C Select your product




DO NOT PLUG IN YOUR CCU7740N WIRELESS USB ADAPTER BEFORE BEING INSTRUCTED !

- Click on the picture of the CGA7740N Wireless Modem Router

> *The next screen will be displayed automatically*

- Follow instructions on the screen for the connection of your gateway

D Enter Internet Service Provider settings



- Select your country and Internet Service Provider (ISP) using the information provided by your ISP

If your ISP is not in the default list, please select **"Other"**.

- Click on **Continue**

> *A progress bar screen will be displayed, your settings will be saved and you will be connected to Internet*

> *The next screen will be displayed*

E Connected to Internet



Once the installation completed, the following screen will be displayed.


- Click on **Menu** in order to install the wireless USB adapter

3111 285 34101

master QSG_CKA7740_EURO.qxd 21/12/2007 13:29 Page 2

2 Install your wireless USB adapter

A Select your product




- Click on the picture of the CCU7740N Wireless USB adapter

> *The next screen will be displayed automatically*

DO NOT PLUG IN YOUR CCU7740N WIRELESS USB ADAPTER BEFORE BEING INSTRUCTED !

B Agree software licence




> *The software end user licence agreement screen is displayed*

- Read carefully and click on **Agree**

> *The next screen will be displayed*

C Connect your wireless USB adapter





- Click on **Continue**

> *A progress bar screen will be displayed and you will be invited to connect your wireless USB adapter*

- Connect your CCU7740N wireless USB adapter

> *The installation will go on and an information screen with Encryption details is displayed*

- Note or print the information by clicking on the **Print** button on the displayed screen.
- Click on **Next>** to continue

> *A progress bar screen is displayed*

> *A confirmation of installation screen is displayed*

3 Enjoy

A Open Internet browser



B Open Internet address



- Enter Internet address
  For example: www.philips.com
- Select **GO**

Wireless freedom

Enjoy the freedom of wireless networking. Your computer is now ready for full use anywhere in your home.

Important information

Microfilters must be plugged in between the wall socket and all devices connected to your telephone line. This includes extension telephones, ADSL modem router and Set up box. Absence of a filter may result in a failure to connect to broadband, interference such as buzzing noises that affect normal telephone calls, or reduced broadband speed and performance.

Welcome to Philips!

Register your product and get support at www.philips.com/welcome

CKA7740N



Quick Start Guide

1. Install your wireless modem router
2. Install your wireless USB adapter
3. Enjoy

PHILIPS