
DAILY REFERENCE GUIDE

THANK YOU FOR BUYING A WHIRLPOOL PRODUCT.
In order to receive a more complete assistance,
please register your appliance on **www.whirlpool.eu/register**

Before using the appliance carefully read *Health and Safety* and *Use and Care* guides.

PRODUCT DESCRIPTION


APPLIANCE



CONTROL PANEL

1. Control panel
Refrigerator compartment
2. LED lighting
3. Fan
4. Fan cover and antibacterial filter area
5. Shelves
6. Multi-flow cold air area
7. Sensor cover
8. Rating plate with commercial name
9. Fruits and vegetables crisper
10. Door reversibility kit
11. Egg tray
12. Door trays
13. Bottle separator
14. Bottle balcony
15. Door seal

Freezer compartment
15. Door seals
16. Upper drawer: coolest zone best for freezing fresh food
17. Ice tray
18. Shelves
19. Freezer drawers




1. STOP ALARM button /ALARM indicator
2. 6th SENSE FRESH CONTROL
3. FAST COOL button
4. FRIDGE TEMPERATURE LEDs
5. PARTY MODE button /KEY LOCK button
6. BLACK OUT ALARM
7. ON/STAND-BY button
8. KEY LOCK indicator
9. FRIDGE TEMPERATURE button


Whirlpool
SENSING THE DIFFERENCE

ACCESSORIES


EGG TRAY



BOTTLE SEPARATOR



ICE TRAY



FIRST TIME USE

HOW TO START THE APPLIANCE

After plugging the appliance to the mains, it starts the operation automatically.
After starting the appliance, wait at least 4-6 hours before placing food into the fridge and into the freezer compartment.

When the appliance is connected to the power supply, the display lights up and all the icons appear on the display for approximately 1 second. The default (factory) values of the fridge compartment settings light-up.

DAILY USE

See Use and Care Guide for more details on functions / see last page for information on how to obtain the Use and Care Guide

FUNCTIONS

ON/STANDBY

To put the product in Stand-by, **press and hold the On/Stand By button for 3 seconds.** All the indicators turn off except On/ Standby indicator.

Press again to reactivate the appliance.

SMART DISPLAY
This optional function can be used to save energy. To activate the Smart Display, press Fridge Temperature and Party Mode buttons at the same time for 3 seconds until an audible signal sounds. To deactivate this function repeat the same procedure. Remember that this function does not disconnect the appliance from the power supply, but only reduce the power consumed by external display.

TEMPERATURE SETTING
To adjust the Fridge Temperature, press the Fridge Temperature button. The Fridge Temperature can be adjusted between +2°C and + 8°C, as shown by the Fridge Temperature LEDs.

PARTY MODE
Press to activate/deactivate the Party Mode function. Use this function to chill drinks inside the freezer compartment.
Important: do not leave the bottle inside the freezer compartment longer than the function is active (30 minutes)

KEY LOCK
To lock/unlock the keys of the Control Panel, press the Party Mode button for 3 seconds: the Key Lock indicator will be displayed for a short time and an acoustical signal will be played.


6TH SENSE FRESH CONTROL
This function automatically works to ensure the optimal conditions to preserve the stored food. If there are any variations, 6th Sense Fresh Control immediately restores the ideal conditions. Results are outstanding: freshness preserved at best throughout the fridge cavity up to 4 times longer.

FAST COOL
Using Fast Cool function it is possible to increase the cooling in the refrigerator compartment. The use of this function is recommended when placing a very high quantity of food in the refrigerator compartment. Press the Fast Cool button to activate Fast Cool function. When activated, the Fast Cool indicator will turn on. The function is automatically disabled after 6 hours, or can be manually disabled by pressing Fridge °C button.

REFRIGERATOR LIGHT
The light system inside the refrigerator compartment uses LEDs light, allowing a better lightning as well as a very low energy consumption.
If the LED light system does not work, please contact the Service to replace it.

Important: The refrigerator compartment light switches on when the refrigerator door is opened. If the door is kept open for more then 10 minutes the light will be automatically switched off.

FAN + ANTIBACTERIAL FILTER
The Fan improves temperature distribution inside the refrigerator compartment, allowing better preservation of stored food.
If the appliance has the Fan it can be equipped with the antibacterial filter.
Remove it from the box placed in the crisper drawer and insert into the fan cover - as in the picture.
The replacement procedure is included in the filter box.




ALARM TABLE

ALARM TYPE	Signal	Cause	Cure
Door open alarm	The acoustical alarm is activated and the Alarm Indicator blinks.	The Fridge or Freezer door has remained open for more than 2 minutes.	Close the door or press the Stop Alarm to mute the acoustical alarm.
Temperature alarm	The acoustical alarm is activated and the Alarm Indicator remains on.	Inside the Freezer the temperature is not adequate	Press the Stop Alarm button ; the acoustical alarm stops, the Alarm Indicator remains on until a temperature < -10°C is reached.
Party Mode alarm	The Party Mode Indicator blinks and the acoustical alarm is activated.	30 min. elapsed since Party Mode function has been activated. It is time to take out the bottle from the freezer (see Use and Care Guide for more details).	
Long black-out alarm	The Black Out Alarm icon remains on, the Alarm indicator blinks.	Prolonged power failure, able to cause the inside temperature to increase to 0°C.	Press the Stop Alarm button ; the acoustical alarm stops, the Alarm Indicator remains on until a temperature < -10°C is reached.
Malfunction	3 central LEDs in the Fridge Temperature LEDs blinks on the display.	Product malfunction.	Contact the After-sales Service.

Whirlpool
SENSING THE DIFFERENCE

HOW TO STORE FOOD AND BEVERAGE



Legend

TEMPERATE ZONE Suggested for the storage of tropical fruit, cans, drinks, eggs, sauces, pickles, butter, jam

COOL ZONE Suggested for storage of cheese, milk, daily food, delicatessen, yogurt, cold cuts, desserts

FRUIT & VEGETABLE DRAWER

FREEZING ZONE DRAWER
(MAX COOL ZONE) Suggested to freeze fresh/cooked food.

FREEZER DRAWERS

Note: The Grey tone of the legend doesn't match with the color of drawers

FRIDGE COMPARTMENT

Use recyclable plastic, metal, aluminum and glass containers and cling film to wrap foods.

Always use closed containers for liquids and for food that may give off or be tainted by odor or flavor transfer or cover them.

If you have a little quantity of food to store in the refrigerator, we recommend to use the shelves above the crisper for fruits and vegetables since this is the coolest area of the compartment.

Foods which give off a large amount ethylene gas and those that are sensitive to this gas, such as fruit, vegetables and salad, should always be separated or wrapped so as not to reduce the storage life; for example do not store tomatoes together with kiwi fruits or cabbage.

To avoid bottles falling over, you can use the bottle holder (available on selected models).

Do not store food too close together to enable sufficient air circulation.

FREEZER COMPARTMENT

The freezer is the ideal storage location for store frozen food, make ice cubes and freeze fresh food in the freezer compartment.
The maximum number of kilograms of fresh food that can be frozen within a 24-hour period is indicated on the rating plate (… kg/24h).
If you have a little quantity of food to store in the freezer, we recommend to use the coldest areas of your freezer compartment, corresponding to the middle area.

MAINTENANCE AND CLEANING AND PROBLEM SOLVING
For maintenance and cleaning and for Problem Solving see the ***Use and Care Guide***.

The ***Use and Care Guide*** can be obtained by:
> After-Sales Service; phone number see in warranty booklet.
> download from Whirlpool Website http://docs.Whirlpool.eu

CONTACTING AFTER-SALES SERVICE
Provide both numbers shown on the service sticker when contacting the After-Sales Service team. http://www.whirlpool.eu

The technical information are situated in the rating plate on the internal side of the appliance.



Whirlpool® Registered trademark/TM Trademark of Whirlpool group of companies -
© Copyright Whirlpool Europe s.r.l. 2014. All rights reserved - http://www.whirlpool.eu

Whirlpool
SENSING THE DIFFERENCE