# DAILY REFERENCE
GUIDE

**THANK YOU FOR PURCHASING A INDESIT PRODUCT**
To receive more comprehensive help and support, please register your product at **www.indesit.com/register**

You can download the Safety Instructions and the Use and Care Guide by visiting our website **docs.indesit.eu** and following the instructions on the back of this booklet.

**Before using the appliance carefully read the Health and Safety guide.**

## PRODUCT DESCRIPTION




**Refrigerator compartment**

1. Electronic control panel / light unit
2. Shelves
3. Rating plate with commercial name
4. Fruits and vegetables crisper
5. Door reversibility kit
6. Door trays
7. Egg tray
8. Bottle holder
9. Bottle balcony
10. Door seal

**Freezer compartment**

10. Door seals
11. Freezer drawers
12. Shelves
13. Bottom drawer: coolest zone best for freezing fresh food
14. Ice tray

### CONTROL PANEL

**B. Thermostat Knob**




- **A.** Light bulb
- **B.** Thermostat knob
- **C.** Thermostat seeting indicator
- **D.** Light button




### TEMPERATURE SETTING

Thermostat set to **MIN**: low cooling intensity
Thermostat set between **MIN** and **MAX** : cooling intensity can be adjusted according to the preferences.
Thermostat set to **MAX**: maximum refrigeration intensity.

*For the best food conservation MED position is recommended.*
*Thermostat set to • : cooling and lighting off.*
Note: Displayed set points correspond to the average temperature throughout the whole refrigerator.

# ACCESSORIES

**EGG TRAY**



**BOTTLE HOLDER**



**ICE TRAY**



# FIRST TIME USE

### HOW TO START THE APPLIANCE

After plugging the appliance to the mains, turn the thermostat knob to switch on the appliance: cooling and light will switch on; set the knob on the desired power (see: "Control panel", at page1).

After starting the appliance, wait at least 4-6 hours before placing food into the fridge and into the freezer compartment.

### REFRIGERATOR LIGHT

To remove the light bulb turn anticlockwise as shown in the picture:



Check the bulb. If necessary unscrew the broken bulb and replace it with a LED bulb of the same type available only at our After-sales Service Centers or authorized dealers.
The refrigerator compartment light switches on when the refrigerator door is opened.

### SOME OF THE FUNCTIONAL SOUNDS YOU MIGHT HEAR

A hissing sound when switching on the appliance for the first time or after a long pause.




A gurgling sound when refrigerant fluid enters into the pipes.




BRRR sound is from the compressor running.




Buzzing sound when water valve or fan start working.




A cracking sound when compressor starts.




The CLICK is from the thermostat which adjusts how often the compressor is running.



# TROUBLESHOOTING GUIDE

| *Problem* | *Possible Cause* | *Solution* |
|---|---|---|
| **THE APPLIANCE IS NOT WORKING** | There may be an appliance power supply problem. | › Check if power cable plugged into a live socket with the proper voltage.<br>› Check if the protection devices and fuses of the electrical system in your home |
| **THERE IS WATER IN THE DEFROST PAN** | This is normal in hot, damp weather. The pan can even be half full. | › Make sure the appliance is level so that the water does not overflow. |
| **THE EDGES OF THE APPLIANCE CABINET, WHICH COME IN CONTACT WITH THE DOOR SEAL, ARE WARM TO THE TOUCH** | This is not a defect.<br>This is normal in hot weather and when the compressor is running. | |
| **THE LIGHT DOES NOT WORK** | The light may need replacing.<br><br>The appliance may be in On/Stand-by model | › Make sure if the protection devices and fuses of the electrical system in your home work well.<br>› Check if the power cable is plugged into a live socket with the proper voltage<br>› In case the LEDs are broken the user must call the Service for exchange of the same type available only at our After-sales Service Centers or authorized dealers. |
| **THE MOTOR SEEMS TO RUN TOO MUCH** | Motor running time depends on different things: number of door openings, amount of food stored, temperature of the room, setting of the temperature controls. | › Make sure that the appliance controls are correctly set.<br>› Check if there is not a large amount of food been added to the appliance.<br>› Check that the door is not opened too often.<br>› Check that the door close properly. |
| **THE APPLIANCE TEMPERATURE IS TOO HIGH** | There could be various causes (see “Solutions”) | › Make sure that the condenser (back the appliance) is free of dust and fluff.<br>› Make sure that the door properly closed.<br>› Make sure that the door seals properly fitted.<br>› On hot days or if the room is warm, the motor naturally runs longer.<br>› If the appliance door has been left open for a while or if large amounts of food have been stored, the motor will run longer in order to cool down the interior of the appliance. |
| **THE APPLIANCE TEMPERATURE IS TOO HIGH** | There could be various causes (see “Solutions”) | › Make sure that the condenser (back the appliance) is free of dust and fluff.<br>› Make sure that the door properly closed.<br>› Make sure that the door seals properly fitted.<br>› On hot days or if the room is warm, the motor naturally runs longer.<br>› If the appliance door has been left open for a while or if large amounts of food have been stored, the motor will run longer in order to cool down the interior of the appliance. |
| **THE DOORS DO NOT OPEN AND CLOSE PROPERLY** | There could be various causes (see “Solutions”) | › Check that food packages are not blocking the door.<br>› Check that the internal parts or automatic ice maker are not out of position.<br>› Check that the door seals are not dirty or sticky.<br>› Ensure the appliance is level. |

# HOW TO STORE FOOD AND BEVERAGE



***Legend***

**TEMPERATE ZONE**

Suggested for the storage of tropical fruit, cans, drinks, eggs, sauces, pickles, butter, jam

**COOL ZONE**

Suggested for storage of cheese, milk, dairy food, delicatessen, yogurt, cold cuts, desserts

**FRUIT & VEGETABLE DRAWER**

**NORMAL FREEZER DRAWERS**

**FREEZING ZONE DRAWER**

(MAX COOL ZONE) Suggested to freeze fresh/cooked food.

Note: The Grey tone of the legend doesn't match with the color of drawers

### FRIDGE COMPARTMENT

Use recyclable plastic, metal, aluminum and glass containers and cling film to wrap foods.

Always use closed containers for liquids and for food that may give off or be tainted by odor or flavor transfer or cover them.

If you have a little quantity of food to store in the refrigerator, we recommend to use the shelves above the crisper for fruits and vegetables since this is the coolest area of the compartment.

Foods which give off a large amount ethylene gas and those that are sensitive to this gas, such as fruit, vegetables and salad, should always be separated or wrapped so as not to reduce the storage life; for example do not store tomatoes together with kiwi fruits or cabbage.

To avoid bottles falling over, you can use the bottle holder (available on selected models).

Do not store food too close together to enable sufficient air circulation.

### FREEZER COMPARTMENT

The freezer is the ideal storage location for store frozen food, make ice cubes and freeze fresh food in the freezer compartment.
The maximum number of kilograms of fresh food that can be frozen within a 24-hour period is indicated on the rating plate (…kg/24h).
If you have a little quantity of food to store in the freezer, we recommend to use the coldest areas of your freezer compartment, corresponding to the bottom area.

### PRODUCT FICHE

www The product fiche with energy data of this appliance can be downloaded from Indesit website **http://docs.indesit.eu**

### HOW TO OBTAIN THE USE AND CARE GUIDE

> www Download the Use and Care Guide from our website **docs.indesit.eu** (you can use this QR Code), specifying the product's commercial code.

> Alternatively, contact our Client After-sales Service.

### CONTACTING OUR AFTER-SALES SERVICE

You can find our contact details in the warranty manual.
When contacting our Client After-sales Service, please state the codes provided on your product's identification plate



400010874917

Printed in Italy



indesit