HyperX ChargePlay™ Duo - PS4 Controller Charger

Set up information

Global Etailers

Launch Date	19th November 2018
Category	Accessories
Part Number	HX-CPDU-C
UPC Code	740617280692
Country of Origin	China
Dimension of Product	185.44 x 87.51 x 74.82mm
Dimension of Packaging	193 x 158 x 85 mm
Unit Net Weight / Unit Gross Weight	374 g / 609 g
Carton Quantity / Dimensions / Weight	10 / 445 x 339 x 227 mm / 6.76 kg
Cartons on a Pallet / Pallet Unit Quantity	36 / 360 (contact Operations for Ocean QTY)
Minimum Purchase Quantity / Optimal qty	10 / 360
Warranty	2 Years

Product Marketing

Title for HyperX	HyperX ChargePlay™ Duo - PS4 Controller Charger
Text Layer	Keep two DUALSHOCK®4 wireless controllers simultaneously charged and ready to play with HyperX ChargePlay™ Duo. Always have a second controller ready for long gaming sessions or multiplayer. Connect your PS4™ controllers to the EXT port and go from empty to full in two hours. ChargePlay Duo has a weighted base and is built for convenience with a simple, secure click-down docking design and 3-level battery indicators that display the controllers' charge status at a glance. HyperX ChargePlay Duo comes with a two-year warranty and free tech support.
Keywords	ps4 docking station, ps4 controller, ps4 charging dock, playstation 4 controller, ps4 charger, ps4 charging station, ps4 controller charger, playstation charging station, playstation 4 controller dock, playstation controller charging station, ps4 dual charger, ps4 remote charger, playstation 4 charging dock, playstation 4 controller charging station, playstation charger, playstation controller charger, ps 4 controller charger, charging station for playstation 4, charging station for ps4 controllers, playstation 4 docking station, playstation 4 dual controller charger, playstation 4 remote charger, dualshock 4 charging station
Bullet Points	• Quickly charges two PS4™ controllers via EXT port • 3-level battery indicators display charging status • Convenient and secure docking with stable design • 2 year warranty

Image Order*

(order from left to right)

If only 1 image slot use #1,

if only 3 slots use #1-#3

* images are in order of how they should be displayed



1. Front (Main image/Hero shot/Thumbnail)



2. Side



3. Packaging front



4. Packaging back