Philips
Power cord

HD5087



Power cord

Please check specifications for compatible products

This power cord connects your device to the mains. Compatible with Saeco, Philips and Gaggia Espresso machines. Note: Length 120 cm

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS

Specifications

Replaceable part

- Fits product types: 10002938, 10000205, 10000206, 10000260, 10001340, 10001823, 10001855, 10002520, 10002743, 10002744, 10002745, 10002746, 10002836, 10002879, 10002929, 10003074, 10003082, 10002880, 10002927, 10000240, 10002600, 10000241, 10000242, 10000243, 10001704, 10001705, 10001707, 10001708, 10001852, 10001853, 10002516, 10002517, 10002518, 10002676, 10002696, 10002770, 10002772, 10003017, 10002775, 10003056, 10002777, 10003060, 10002838, 10002869, 10002925, 10003062, 10003063, 10001802, 10002660, 10002661, 10002933, 1000293300, 10002934, 10003024, 10003026, 10003064, 10003065, 10003066, 10003124, 10003151, 10003152, 1000315200, 10003153, 10003158, 10003217, 10003350, 10000100, 10000264, 10001835, 10001865, 10000290, 10001867, 10000102, 10001837, 10000321, 10001869, 10000104, 10001839, 10000291, 10001868, 10000300, 10003050, 10003051, 10003052, 10003053, 10001883, 10001884, 10001885, 10001886, 10001887, 10001888, 10002815, 10002681, 10002682, 10002683, 10002737, 10001963, 10001964, 10001965, 10002029, 10002814, 10001439, 10001440, 10001441, 10001450, 10001452, 10001454, 10002813, 10001456, 10001458, 10001460, 10001695, 10001696, 10001697, 10003301, 10000070, 10002403, 10002768, 10003083, 10003230, 10000006, 10001290, 10001882, 10002846, 10002890, 10002973, 10003086/EU, 10003087/EO, 10003089/EU, 10003106/EU, 10003134/EO, 10003160/EU, 10003162/EU, 10003163/EO, 10003305/EU, 10003306/EU, 10003307/EU, 10003308/EU, 10003366/EO, 10002550, 10002669, 10003400, 10003401, 10003402, 10003403, 10003404, 10003326, 10003560, 10003604, 10003605, 10003607, 10003608, 10003611, 10003612, 10003722, 10003054, 10003055, 10003286, 10003287, 10003521, 10003524, 10003562, 10003563, 10003565, 10003568, 10003571, 10003566, 10003569, 10003572, 10001801, 10003351, 10003352, 10003360, 10003361, 10003362, 10003363, 10003553, 10003554, 10003559, 10003580, 10003581, 10003583, 10003584, 10003585, 10003588, 10003590, 10003592, 10003593, 10003594, 10003601, 10003741, 10002668, 10002932, 10001459, 10002667, 10003013, 10003721, 10000151, 10002482, 10002307, 10002790, 10002308, 10002791, 10002395, 10002397, 10002760, 10003268, 10002762, 10003269, 10002800, 10002801, 10002953, 10002954, 10002955, 10002956, 10002971, 10003086, 10003231, 10003087, 10003089, 10003233, 10003106, 10003134, 10003160, 10003234, 10003162, 10003236, 10003163, 10003305, 10003306, 10003307, 10003308, 10003366, 10003650, 10003651, 10003652, 10003653, 10003654, 10003655, 10003656, 10003664, 10003665, 10003666, 10003694, 10003708, 10003769, 10003794, 10003795, 10003796, 10003797, 10003798, 10003799, 10003800, 10003801, 10003802, 10003804, 10003810, 10003811, 10003812, 10003824, 10003826, 10003827, 10003844, 10003845, 10003849, 10003860, 10003871, 10003901, 10001706, 710501309
- Fits product type:: 10002307/F, 10002308/F, 10002760/F, 10002762/F, 10002800/F, 10002953/F, 10002954/F, 10002955/F, 10002956/F, 10002971/F, 10002973/F, 10003650/EU, 10003651/EU, 10003652/EU, 10003653/EU, 10003654/EU, 10003655/EU, 10003656/EU, 10003664/EU, 10003665/EU, 10003666/EU, 10003694/EU, 10003708/EU
- Fits Coffee Product: EP3360/00, EP3362/00, EP3363/00, EP3363/10, EP3510/00, EP3519/00, EP3550/00, EP3551/00, EP3551/10, EP3558/00, EP3559/00, EP3559/10, EP4010/00, EP4050/10, EP4051/10, HD8821/11, HD8822/09, HD8824/01, HD8824/09, HD8825/09, HD8826/09, HD8827/01, HD8827/09, HD8827/12, HD8829/01, HD8829/09, HD8830/10, HD8830/12, HD8831/01, HD8831/09, HD8831/11, HD8832/01, HD8832/09, HD8834/11, HD8834/19, HD8841/11, HD8842/09, HD8847/01, HD8847/09, HD8847/11, HD8847/19, HD8848/09, HD8851/01, HD8852/01, HD8852/09, HD8887/19, HD8888/19, HD8889/19, HD8900/01, HD8900/11, HD8902/01, HD8904/01, HD8906/01, HD8911/02, HD8911/21, HD8912/09, HD8913/11, HD8914/01, HD8914/09, HD8915/01, HD8915/09, HD8915/77, HD8916/01, HD8916/09, HD8916/19, HD8918/09, HD8919/51, HD8919/55, HD8919/59, HD8921/01, HD8921/09, HD8922/01, HD8922/09, HD8924/01, HD8924/09, HD8925/01, HD8925/09, HD8926/29, HD8927/01, HD8927/09, HD8928/09, HD8943/12, HD8943/22, HD8944/02, HD8946/02, SM3054/00, SM3054/10, SM3061/10, SM5460/10, SM5470/10, SM5473/10, SM5478/10, SM5479/10, SM7680/00, HD8829/11, SM6480/00, SM6580/00, SM6580/10, SM6580/20, SM6582/10, SM6582/30, SM6585/00, SM6580/50
- Fits product type: EP5360, EP5361, EP5365, EP5960, EP5961

Suitable for:

- XELSIS Model Year 2017: SM7580/00, SM7581/00, SM7680/00, SM7682/00, SM7683/00, SM7684/00, SM7685/00, SM7686/00, SM7581/04, SM7684/04, SM7685/04, SM7685/07

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2023-05-20

Version: 5.5.1

EAN: 87 10103 54976 5

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.