Philips
CD Soundmachine

DVD, CD, USB, FM

Remote Control
4W

AZ5741



Enjoy your movies, music and photos

You can now enjoy your favorite movies, music and even photos from portable USB device on the TV with this all-in-one Philips DVD Soundmachine AZ5741. It plays DVDs, MP3/WMA-CD, Picture CDs and radio.

Everything you need

- Play DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD
- USB Direct for MP3/WMA music playback
- FM tuner for radio enjoyment

Easy to use

- Handy remote control for extra convenience
- On Screen Display for easy navigation

PHILIPS

CD Soundmachine
DVD, CD, USB, FM Remote Control, 4W

AZ5741/98

Specifications

Video Playback
- Playback Media: DVD-Video, DVD+R/+RW, Picture CD, Video CD/SVCD
- Disc Playback Modes: A-B Repeat, Fast Backward, Fast Forward, OSD, Pause, PBC, Zoom

Audio Playback
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play, 20-Track Programmable
- Loader Type: Top
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Shuffle

Tuner/Reception/Transmission
- Antenna: FM Antenna
- Tuner Bands: FM

Sound
- Output power (RMS): 4W
- Speaker diameter: 4"
- Sound System: Stereo
- Volume Control: rotary

Loudspeakers
- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker types: Loudspeakers

Connectivity
- AV output: Ext 3.5 mm jack x1
- Headphone: 3.5 mm
- USB: USB host

Convenience
- Display Digits: 7
- Display Type: LCD

Accessories
- Included accessories: Remote Control, AC Power Cord, Audio/Video cable, User Manual, Warranty Leaflet

Dimensions
- Product dimensions (WxDxH): 401 x 243 x 172 mm
- Packaging dimensions (WxDxH): 453 x 196 x 275 mm
- Product weight: 3.1 kg
- Weight incl. Packaging: 3.9 kg

Power
- Mains power: 220 - 240V and 110 - 127V, 50/60Hz AC voltage selectable

Highlights

PlayDVD,VCD,MP3-CD,CD(RW)&Pict



The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD". The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

Issue date 2014-09-27
Version: 2.0.1
12 NC: 8670 000 88293
EAN: 87 12581 63886 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com

* Music with Digital Right Management not supported.