Dell Pro 5 16

P516260

Re-imaging Guide for Windows

Regulatory Model: P151F
Regulatory Type: P151F001/P151F003/P151F004
September 2026
Rev. A01

DELL Technologies

Notes, cautions, and warnings

NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

Copyright © Dell Inc. All Rights Reserved. Dell Technologies, Dell, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

Chapter 1: Installation overview **4**

Chapter 2: Introduction **5**

Chapter 3: Order of reinstallation **6**

Chapter 4: Updating or resetting the BIOS **7**
Updating the BIOS in Windows 7
Trusted Platform Module (TPM) security 7

Chapter 5: Reinstalling the operating system **8**

Chapter 6: Reinstalling drivers and applications **9**
Displaying drivers and applications on your computer 9

Chapter 7: Reinstallation sequence for drivers and applications **10**
Intel Chipset Device Software 10
Downloading and installing the chipset driver 10
Critical Microsoft Knowledge Base (KB) updates 10
Graphics driver 10
Downloading and installing the graphics driver 11
Audio driver 11
Downloading and installing the audio driver 11
Dell Optimizer 11
Wireless Local Network (WLAN) drivers 11
Downloading and installing the Wi-Fi driver 12

Chapter 8: .NET Framework **13**

Chapter 9: Getting help and contacting Dell **14**

Chapter 10: Revision history **15**

1

Installation overview

CAUTION: This section of the re-imaging guide covers driver installation and driver updates and is designed for system administrators. Do not attempt to install or update drivers on the system if you are not an administrator or if you are unsure of the procedures. Failure to follow instructions may result in permanent data loss.

NOTE: The information that is provided in this guide is only applicable to computers shipped with the Windows 11 operating system.

NOTE: Dell Technologies recommends that you download and install the device drivers from the Dell Drivers & Downloads website. Installing device drivers from a non-Dell website can cause system performance issues, corrupt operating system files, blue screen errors, unexpected shutdowns, or infect your computer with malicious software.

Update device drivers after reinstalling the operating system or when you experience issues with networking, graphics, sound, or other hardware. Dell Technologies recommends that if you have performed a factory reset of your Dell computer, you install or update device drivers.This ensures that you have the latest device drivers that are installed on your computer and that the devices function optimally.

Installing or updating device drivers may lead to the following improvements:

- Increases in system performance
- Patched security risks
- Expanded compatibility
- Fixed device issues
- Support for new features

However, if your computer operates normally and Windows does not prompt any driver issues or updates, you may not need to update the drivers.

Review the importance of each driver update on the Dell Drivers & Downloads page before assessing the need to continue with an update.

2

Introduction

CAUTION: This re-imaging guide is designed for system administrators. Do not attempt to re-image the computer if you are not an administrator or are unsure of the procedures. Failure to follow instructions may result in permanent data loss.

NOTE: The information that is provided in this guide is only applicable to computers shipped with the Windows 11 operating system.

Re-imaging is the process of removing all software on the computer and reinstalling the removed software. Re-imaging is required when the software is corrupted or damaged and can also remove harmful or malicious software in your computer. This re-imaging guide provides the steps that are required for re-imaging your computer.

This guide assists you in installing Dell-recommended software stack and settings, drivers, and applications, which are tested and validated on your computer. The installation of the listed drivers and applications as described in the guide enhances the optimal performance of your computer.

Dell also provides drivers and applications that are not included with the Windows operating system. These drivers are required to enable the following solid-state drives (SSDs):

- 1 TB PCIe SSD
- 2 TB PCIe SSD

It is always recommended to re-image on a newly installed operating system and not from any previous image-build. Ensure that the BIOS settings, including SATA configurations and modes, are appropriately set and the latest drivers and applications are used when re-imaging the computer.

3

Order of reinstallation

NOTE: Some drivers and application installation steps may not be applicable, depending on the configuration of the computer that you have ordered.

To achieve optimal performance, install the drivers and applications in the following sequence:

1. **BIOS**: The BIOS enables the operating system to be loaded into the memory and enables the initial setup process on your computer.
2. **Windows operating system**: The operating system controls the hardware of the computer and provides a base on which other software can operate.
3. **Intel chipset driver**: Allows Windows to communicate and adjust settings on components on the system board which includes:
   - Intel Chipset Device Software Driver
   - Intel Management Engine Components Installer
   - Intel Serial I/O Driver
   - Intel HID Event Filter Driver
   - Intel Dynamic Tuning Driver
   - Intel Integrated Sensor Solution Driver
   - Intel AI Boost Driver
   - Intel Platform Monitoring Technology Driver (PMT)
   - Intel Innovation Platform Framework
   - Intel Processor Power Management Utility
   - Intel NPU Driver
4. **Networking and communication drivers**, which include:
   - Wireless Local Area Network (WLAN) adapter driver: Enables and enhances the wireless adapter.
   - Bluetooth driver: Enables and enhances the Bluetooth adapter.
   - Intel PCIe Ethernet Controller Driver(Optional).
   - Realtek USB GBE Ethernet Controller Driver.
   - Dell Wireless 5933e and MediaTek T700 Firmware and GNSS and GPS Driver (Optional).
   - Dell Wireless 5826e and Qualcomm Snapdragon X12 Firmware and GNSS and GPS IOT Driver (Optional).
5. **Install the latest updates and drivers**: Dell Command Updates (DCU).

   NOTE: Drivers can be downloaded and installed manually from the Drivers & Downloads.

6. **Critical Microsoft Knowledge Base (KB) updates**: Microsoft updates that fix and optimize the operating system. For more information, see Windows release information.
7. **Graphics driver**:
   - Enhances and optimizes video performance.
   - Enables and provides additional functionality that is not included in the native Microsoft VGA driver, including:
     - User-customizable power management features
     - Portability and behavioral profiles
     - Multiple-monitor support
8. **Audio driver**: Enables and enhances the audio controller.
9. **Dell applications**, which include:
   - Dell Command Update application
   - Dell Optimizer (DO)
10. **Security device**, which includes:
    - Fingerprint Sensor Driver
    - Dell ControlVault3 Plus Driver and Firmware
    - Intel Total Storage Encryption Driver(TSE)
11. **Microsoft Windows Studio Effects Driver**.

4

Updating or resetting the BIOS

Updating the BIOS in Windows

It is recommended to update the BIOS is Windows when an update is available or when you replace the system board.

1. Go to Dell Support Site.
2. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

3. Click **Drivers & Downloads**.
4. From the **Operating system** drop-down list, select the operating system that is installed on your computer.
5. From the **Category** drop-down list, select **BIOS**.
6. Select the latest version of BIOS, and click **Download** to download the BIOS file for your computer.
7. After the download is complete, browse the folder where you saved the BIOS update file.
8. Double-click the BIOS update file icon and follow the on-screen instructions.
   For more information, see knowledge base article at Dell Support Site.

Trusted Platform Module (TPM) security

TPM must be enabled in the BIOS setup program for it to be deployed on the computer. Follow these steps to enable and configure the TPM:

1. Turn on or restart your computer.
2. Press F2 when the Dell logo is displayed on the screen to enter the BIOS setup program.
   The BIOS setup program is displayed.
3. On the left pane, select **Security**.
4. Select or clear any of the following options to enable or disable it, respectively:
   - **TPM 2.0 security On**: The TPM is enabled and activated.
   - **Clear**: The BIOS clears the information that is stored in the TPM.
5. Save the settings and exit.

5

Reinstalling the operating system

The Windows operating system is validated for use on this computer. You can reset or reinstall the operating system under different scenarios. For more information about reinstalling the operating system, see the knowledge base article 000192698 at Dell Support Site.

You can use Dell BIOSConnect to recover the operating system of your computer. See the knowledge base article 000177771 at Dell Support Site.

Before attempting a reinstall of your operating system, Dell recommends that you backup all data as described in the Microsoft knowledge base article.

NOTE: If you are removing the factory-installed operating system to deploy the image for your organization, make sure to use DiskPart or a similar tool to create an EFI partition larger than 384 MB. The characteristics of the EFI partition should be file system of FAT32 and disk type should be GPT (GUID Partition Table).

After you reinstall the operating system on this computer, Dell recommends that you update the System BIOS to the latest version.

NOTE: Execute command `bios.exe /f` to enforce a consistent BIOS update across deployments.

Downloading the latest System BIOS

1. Go to the Dell Support Site.
2. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

3. Click **Drivers & Downloads**.
4. From the **Category** drop-down list, select BIOS.
5. Click **Download** to download the system BIOS for your computer.

   NOTE: Make sure you select Dell Pro 5 16 P516260 System BIOS version 2.1.6 or higher for the update.

6. Follow the accompanying instructions and release notes to complete the update.

6

Reinstalling drivers and applications

Drivers and applications are software that enables the Windows operating system to communicate with the hardware devices and software in your computer. Devices such as video and sound cards require drivers to function correctly within the Windows operating system, and enable you to adjust hardware settings.

The Windows operating system includes drivers for most devices, but device-specific drivers may have to be downloaded and installed separately. Dell Technologies recommends that you download the device drivers for your computer from Drivers & Downloads.

Applications must be downloaded and installed separately. Dell Technologies recommends that you download the required applications for your Dell computer from the Dell Download Center.

Displaying drivers and applications on your computer

1. Turn on your computer.
2. Go to the Dell Support Site.
3. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

4. Click **Drivers & Downloads**.
5. From the **Operating system** drop-down list, select the Windows operating system that is installed on your computer to get a list of the drivers and applications available for your computer.

7

Reinstallation sequence for drivers and applications

Driver installation is critical after reinstalling the Windows operating system on your Dell computer. Install the drivers in the correct sequence for your computer to function correctly. In some scenarios, you may have to reinstall or update the device driver if you are encountering issues with a specific device.

For more information, see the Dell knowledge base article 000132394 at the Dell Support Site.

NOTE: The Windows operating system includes touchpad drivers; no other touchpad-driver installation is required.

NOTE: The Windows operating system includes the webcam driver; no additional webcam-driver installation is required. For video capture or streaming, users can install the webcam software available from third-party providers.

Dell Technologies recommends installing drivers or applications in the following sequence.

Intel Chipset Device Software

The Windows operating system may not include the updated Intel Chipset Device Software for Dell computers. The Intel Chipset Device Software is available at the Dell Support Site.

Downloading and installing the chipset driver

1. Turn on the computer.
2. Go to the Dell Support Site.
3. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

4. Click **Drivers & Downloads**.
5. From the **Category** drop-down list, select **Chipset**.
6. Click **Download** to download the chipset driver for your computer.
7. After the download is complete, go to the folder where you saved the chipset driver file.
8. Double-click the chipset driver file icon and follow the on-screen instructions.

Critical Microsoft Knowledge Base (KB) updates

Dell Technologies recommends installing all the latest available KB updates on your computer. KB updates are automatically downloaded and installed when Windows Updates are enabled and can also be manually downloaded and installed from the Microsoft support site. For more information, see Windows release information.

Graphics driver

The Windows operating system includes the VGA-graphics driver only. For optimal graphics performance, install the Dell graphics driver applicable to your computer from the Dell Support Site.

Downloading and installing the graphics driver

1. Turn on your computer.
2. Go to the Dell Support Site.
3. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

4. Click **Drivers & Downloads**.
5. From the **Category** drop-down list, select **Video**.
6. Click **Download** to download the preferred graphics driver for your computer.
7. After the download is complete, go to the folder where you saved the graphics driver file.
8. Double-click the graphics driver file icon and follow the on-screen instructions.

Audio driver

The Windows operating system does not include the audio driver that is recommended by Dell. Install the HD audio driver available for download from the Dell Support Site.

Downloading and installing the audio driver

1. Turn on your computer.
2. Go to the Dell Support Site.
3. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

4. Click **Drivers & Downloads**.
5. From the **Category** drop-down list, select **Audio**.
6. Click **Download** to download the preferred audio driver for your computer.
7. After the download is complete, go to the folder where you saved the audio driver file.
8. Double-click the audio driver file icon and follow the on-screen instructions.

Dell Optimizer

Dell Optimizer is an application that is designed to enhance computer performance and productivity by optimizing settings for power, battery, display, and presence detection. It also provides access to applications purchased with your new computer.

For more information, see *Dell Optimizer User's Guide* at Dell Support Site.

Wireless Local Network (WLAN) drivers

The Windows operating system does not provide native-device driver support for WLAN controllers on Dell computers. To obtain wireless network functionality, install the relevant WLAN drivers from the Dell Support Site.

Downloading and installing the Wi-Fi driver

1. Turn on the computer.
2. Go to the Dell Support Site.
3. In the **Search support** field, enter the Service Tag, Serial Number, Service Request, Model, or Keyword of your computer, and then click **Search**.

   NOTE: If you do not have the Service Tag, Serial Number, Service Request, Model, or Keyword, use the SupportAssist feature to automatically identify your computer. You can also click **Browse all products** to manually browse for your computer.

4. Click **Drivers & Downloads**.
5. From the **Category** drop-down list, select **Network, Ethernet & Wireless**.
6. Click **Download** to download the preferred Wi-Fi controller and Bluetooth drivers for your computer.
7. After the download is complete, go to the folder where you saved the driver files.
8. Double-click the file icon of each driver file, and follow the on-screen instructions.

8

.NET Framework

The .NET Framework is a software framework from Microsoft, which is bundled with Windows operating systems. The .NET Framework is intended to be used by applications created for the Windows platform.

9

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 1. Self-help resources

Self-help resources	Resource location
Information about Dell products and services	Dell Site
Tips	
Contact Support	In Windows search, type `Contact Support`, and press Enter.
Online help for operating system	Windows Support Site
Access top solutions, diagnostics, drivers and downloads, and learn more about your computer through videos, manuals, and documents.	Your Dell computer is uniquely identified using a Service Tag or Express Service Code. To view relevant support resources for your Dell computer, enter the Service Tag or Express Service Code at Dell Support Site. For more information about how to find the Service Tag for your computer, see Locate the Service Tag on your computer.
Dell knowledge base articles	1. Go to Dell Support Site. 2. On the menu bar at the top of the Support page, select **Support** > **Support Library**. 3. In the Search field on the Support Library page, type the keyword, topic, or model number, and then click or tap the search icon to view the related articles.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see Dell Support Site.

NOTE: Availability of the services may vary depending on the country or region, and product.

NOTE: If you do not have an active Internet connection, you can find contact information in your purchase invoice, packing slip, bill, or Dell product catalog.

10

Revision history

Tracks all updates that are made to the document. It typically includes the date of change, version number, and a brief description of the modification. This log helps maintain transparency, accountability, and a clear timeline of progress.

Table 2. Revision history

Revision	Date	Description
A01	September 2026	Updated the reinstalling the operating system topic.
A00	May 2026	Original publish date.