

Philips Toaster

HD2647/20

- 4 slot
- 2 function
- Metal square
- Reheat, defrost

Enjoy great toast together

Toaster for bread that's always golden brown

- To toast 2 slices independently or 4 at the same time
- Evenly toasts thick or thin slices
- Extra-wide and extra-deep slot(s) to fit your bread
- Removable crumb tray for easy cleaning
- Defrost and toast frozen bread at any browning level
- The outside of the toaster stays cool and safe to touch
- High lift feature to safely take out small pieces of bread
- Reheat setting warms or further browns just toasted bread
- Cancel button stops toasting at any time

Highlights

Double 2-slice operation



Independent double 2-slice operation to toast 2 slices independently or four at the same time for optimal flexibility and convenience.

Variable-width bread slots



Evenly toasts thick or thin slices.

Extra-wide and extra-deep slot(s)

Extra-wide and extra-deep slot(s) to fit your bread.

Removable crumb tray



Is easy to clean thanks to its removable crumb tray.

Frozen bread function

Cool wall exterior



The outside of the toaster stays cool and safe to touch.

High lift feature



High lift feature to safely take out small pieces of bread.

Reheat setting



Cancel button

Specifications

General specifications

Cord storage: Yes
Non-slip feet: Yes
Automatic safety shut-off: Yes
Multiple toast settings: 7

Technical specifications

Slot size (L x W x H): 136 x 28 x 130 mm
Power: 1800 W
Voltage: 220-240 V
Cord length: 0.85 cm
Frequency: 50/60 Hz

Design specifications

Colour(s): Metal/black

Publication Date
2025-09-06
Version: 1.1.1
www.phillips.com

2025 © Versuni Holding B.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.