Philips
CD Soundmachine

USB
Black & Grey

AZ390



Enjoy your music wherever you go

with USB direct

Want to enjoy the music collections stored at portable music player without using headphone? Plug the USB Direct socket to the Philips CD soundmachine and enjoy your favorite digital music through the powerful speakers - anytime, anywhere.

Enjoy your music from different sources

- USB Direct for MP3 music playback
- Play MP3-CD, CD and CD-R/RW
- FM tuner for radio enjoyment
- Audio-in for easy portable music playback

Easy to use

- CD Shuffle/Repeat for personalized music enjoyment
- 20-track CD programmable

PHILIPS

CD Soundmachine
USB Black & Grey

AZ390/12

Specifications

Audio playback
- Playback media: CD, CD-R, CD-RW, MP3-CD
- Disc playback modes: fast forward/backward, next/previous album search, next/previous track search, repeat/shuffle/program

Tuner/Reception/Transmission
- Tuner bands: FM
- Antenna: FM antenna

Sound
- Sound system: stereo
- Volume control: rotary (analogue)
- Output power: 2 x 1 W RMS

Loudspeakers
- No. of built-in speakers: 2

Connectivity
- USB: USB host
- Audio in (3.5mm)

Power
- Power supply: AC or battery input
- Mains power: AC 220 - 240V
- Battery type: C size (LR14)
- Battery voltage: 1.5 V
- Number of batteries: 6

Convenience
- Display Digits: 3
- Display type: LCD display
- Loader type: top

Accessories
- Cables/Connection: power cord
- Warranty: Warranty leaflet
- Others: User Manual

Dimensions
- Product dimensions (WxDxH): 243 x 199 x 124 mm
- Packaging dimensions (WxDxH): 283 x 164 x 241 mm
- Product weight: 1.4 kg
- Weight incl. Packaging: 1.8 kg

Highlights

USB Direct for MP3 music
USB Direct for MP3 music playback

Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3") .MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

CD Shuffle/Repeat



The "Shuffle/Repeat" function helps you to get rid of the boredom of hearing your music played in the same order all the time. After loading your favorite songs to the player, all you have to do is to select one of the modes - "Shuffle" or "Repeat" for your tunes to be played in different modes order. Enjoy the different and unique music experience every time you hook up to your player.

20-track CD programmable
The CD progammable playback feature allows you to enjoy your favorite tracks in the sequence you want.

Issue date 2015-04-10
Version: 1.0.5
12 NC: 8670 001 16684
EAN: 48 95185 60140 3

© 2015 Koninklijke Philips N.V.
All Rights reserved.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com