Installation Instruction
Workabout Pro Short 802.11/GSM Rubber Case

1. Installation

- Figure A: Insert Workabout Pro Short handheld through opening of rubber boot and securely fit the front end of the Workabout Pro Short handheld in the end of the rubber boot.
- Figure B & C: Firmly pull bottom corners of rubber boot (one at a time works best) around the end of the Workabout Pro Short handheld until securely enclosed.
- Figure D: Complete.



Figure A

Part No. 1003507-001 Revision A



Figure B



Figure C



Figure D

COMPANY HEADQUARTERS AND CANADIAN SERVICE CENTRE
PSION Inc.
2100 Meadowvale Boulevard, Mississauga
Ontario, Canada L5N 7J9
Tel: +1 905 813 9900
Fax: +1 905 812 6300
E-mail: salescdn@psion.com
www.psion.com
www.ingenuityworking.com