



PHILIPS


4404.016.98811
Last update: 18/08/14

























© Copyright

440401698811.indd 1 9/19/2014 5:08:31 PM


PHILIPS

9





10



! 若频繁切换亮度模式，出现多灯亮度明显不一致时，请关灯8秒以上再开灯，即可恢复一致。

! Once the different brightness of downlights occurred due to frequent switching among light levels, please switch off the downlights for at least 8 seconds and turn on, all down -lights will come back to 100% brightness.

PHILIPS (CHINA) INVESTMENT CO., LTD.
1602-1605, No. 218 Tian Mu Xi Road, Shanghai, PRC 200070.
飞利浦(中国)投资有限公司
上海市天目西路218号1602-1605（邮编：200070）

440401698811.indd 2 9/19/2014 5:08:32 PM