PHILIPS



Philips Pusher

CP9546/01

to replace your current pusher

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All of this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HR1870/05, HR1870/10, HR1870/70, HR1871/05, HR1871/10, HR1871/11, HR1871/15, HR1871/70, HR1872/30, HR1873/00, HR1873/72, HR1874/70, HR1876/70, HR1871/71, HR1874/74, HR1869/00, HR1869/01, hr1869/05, HR1869/30, HR1869/31, HR1869/35, HR1869/60, HR1869/61, HR1869/70, HR1869/71, HR1869/80, HR1870/00, HR1870/15, HR1874/00, HR1871/00

Publication Date
2025-08-23
Version: 4.4.1
www.phillips.com

2025 © Versuni Holding B.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.