

Philips Espresso Water container

CP0228/01

- PicoBaristo, Incanto, EP and SM s.
- Transparent
- Not dishwasher-proof

Water tank

Please check specifications for compatible product

- Easily renew your product with original Philips parts

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All of this with guaranteed Philips quality.

Specifications

Replaceable part

Fits product types:: HD8911, HD8914, HD8917

Fits Coffee Product: EP3559/10

Fits product type: HD8927, HD8924, HD8915/01, HD8915/09, HD8921/01, HD8921/09, HD8925/01, HD8925/09, EP3550/00, EP3551/00, EP4010/00, EP4050/00, SM3061/00, EP4051/00, EP3363/10, EP3362/00, EP3363/00, EP3551/10, EP3558/00, EP3559/00, EP5360, EP5361, EP5365, EP5960, EP5961, EP5330, EP5331, EP5333, EP5334, EP5335, EP5930, EP5934

Publication Date
2025-08-23
Version: 6.6.1
www.phillips.com

2025 © Versuni Holding B.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.