Philips WelcomeBell 300
AddPush
Additional call button

Manage a second entrance

Weather-resistant
Low battery warning
Customisable doorbell melody

DES7000WPB



Second entrance to your doorbell

With additional light-up call button

Manage another entrance to your home with this extra WelcomeBell 300 AddPush call button. Compatible with the entire Philips WelcomeBell 300 range, it can be used with four chimes max. It is weather-resistant.

To be used for an additional entrance
- If you have several entrances

Low battery alert
- Flash + beep when battery is low.

Resistant
- Call button that can be used no matter the weather

Suited to your needs
- A doorbell melody for each transmitter
- Call button to be used with four chimes max.

PHILIPS

Additional call button

Manage a second entrance Weather-resistant, Low battery warning, Customisable doorbell melody

DES7000WPB/10

Specifications

Electrical features
- Transmitter: 2 x AAA (LR03) (not included)

Finish
- Transmitter: White and transparent plastic

Kit features
- Dimensions: 115(h) x 70(l) x 35(d) mm

Maximum distance
- Frequency: 433MHz
- Wireless: 300m in open air

Operating temperature
- Temperature range: -10°C / 55°C

Warranty
- Years: 2

Wiring
- Circuit: Wireless

Standard and certification
- Type: CE, RoHS, REACH

operation
- Transmitter: Outdoor (IP65)

Transmitter specifications
- Illuminated call button
- Illuminated name plate
- Installation: Wall
- Low battery warning: Yes (flash + beep)
- Max no. of receivers: 4

Highlights

Additional call button
Do you have several entrances to your home? Use this additional WelcomeBell 300 AddPush call button to greet your guests at another entrance. It has a very long range of 300m and is ideal to be installed where you wish.

Customisable doorbell melody
It's practical – you can choose the doorbell melody you wish for each transmitter you own. When the melody sounds, you will immediately know which of your mobile doorbell transmitters is ringing.

Low battery alert
There's no risk of your Philips call button letting you down. With its beep + flash alert, you are notified when the batteries are low. You'll just need to change them.

Outdoor protection
Whether it is raining or snowing, you will always be able to use your Philips call button. It's all weather-resistant (IP65) and is installed problem-free to your home's outdoor wall.

Scalable platform
Link this call button with up to four wireless chimes from the Philips WelcomeBell 300 range. Practical if you wish to be alerted to your guests' arrival no matter which room you are in. In total, with this upgradeable system, you can have up to four chimes and four transmitters (call button, motion detector, door/window opening detector) that can be used together.

Issue date 2018-08-22

Version: 2.0.1

12 NC: 8670 001 50026
EAN: 33 45115 31016 1

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com