# Original HP InkJet Value Packs

## December 2017

CISMEA



| HP InkJet Printers | HP 178 Series Photosmart Photo Value Pack 10 × 15 cm/50 sheets[1] |
|---|---|
| | T9D89HE |
| **HP DeskJet** | |
| HP DeskJet F370 | |
| HP DeskJet F375 | |
| HP DeskJet F380/F390 | |
| HP DeskJet 450ci/450cbi/450wbt | |
| HP DeskJet 460c/cb/wbt/wf | |
| HP DeskJet 600/HP Deskwriter 600 series | |
| HP DeskJet 660c/670c/HP Deskwriter 660c/670c | |
| HP DeskJet 690c series/695c | |
| HP DeskJet 710c/720c/722c/815c | |
| HP DeskJet 810c | |
| HP DeskJet 820cXi/850c/870cXi | |
| HP DeskJet 816c/825c/840c/843c/845c | |
| HP DeskJet 880c/890c/895cXi | |
| HP DeskJet 916c/920c/940c/HP Color Copier 310 | |
| HP Color Copier 290 | |
| HP DeskJet 930c/cm /950c/959c | |
| HP DeskJet 960c/970cXi/980cXi/990cXi/cm/995c | |
| HP DeskJet 1100c | |
| HP DeskJet 1120c/1125c | |
| HP DeskJet 1000/1050/1510/2000/2050/3000/3050 | |
| HP DeskJet 1050A/2050A/2054A/3050A e-All | |
| HP DeskJet 3070A | • |
| HP DeskJet 1200c/ps | |
| HP DeskJet 1180c/1220c/1220c/ps/1280 | |
| HP DeskJet 1600c/cm | |
| HP DeskJet 3320/3325/3420/3425 series | |
| HP DeskJet 3520/3535/3550/3745 | |
| HP DeskJet 3645/3647/3650/3845 | |
| HP DeskJet 3810/3816/3820/3822 series | |
| HP DeskJet 3920/3940 | |
| HP DeskJet 5145/5150/5151/5550/5552 | |
| HP DeskJet 5650/5652/5655 | |
| HP DeskJet 5443 | |
| HP DeskJet 5743 | |
| HP DeskJet 5850 | |
| HP DeskJet 5943 | |
| HP DeskJet 6122/6127 | |
| HP DeskJet 6543/6543d/6623/6843/6843d/9803/9803d | |
| HP DeskJet 6943 | |
| HP DeskJet 6983 | |
| HP DeskJet 9300 | |
| HP DeskJet 9650/9670/9680/9680gp | |
| HP DeskJet D1360/D1460/D1470/D1560 | |
| HP DeskJet 2130 | |
| HP DeskJet D2330/D2360/D2430/D2460 | |
| HP DeskJet D1663/D2563/D2663/D5563 | |
| HP DeskJet D4163 | |
| HP DeskJet D4263/D4363 | |
| HP DeskJet F2180/F2187/F2280/F2290 | |
| HP DeskJet F4140 | |
| HP DeskJet F4172 | |
| HP DeskJet F4180 | |
| HP DeskJet F4190 | |
| HP DeskJet F2423/F2483/F2493/F4213/F4275/F4283/F4583 | |
| HP DeskJet Ink Advantage 1015/1510/1515 All/1516/2515/2545 e-All/ 2645 All/2646/3515 e-All[6] | |
| HP DeskJet Ink Advantage 3525/4615/4625 e-All/5525/6525[6] | |
| HP DeskJet Ink Advantage 1115/2135/3635/3835/4535/4675 | |
| HP DeskJet Ink Advantage 5575/5645 | |
| HP DeskJet Ink Advantage 2520hc/2020hc | |
| **HP OfficeJet** | |
| HP Digital Copier 410 | |
| HP CopyJet/M | |
| HP Color InkJet CP 1700 series/HP Business InkJet 2600 series | |
| HP Business InkJet 1000 | |
| HP Business InkJet 1100 series | |
| HP Business InkJet 1200 series | |
| HP Business InkJet 2200 series/2300 series | |
| HP Business InkJet 2800 series | |
| HP Business InkJet 3000 series | |
| HP OfficeJet t45/t65/r45/r65 | |
| HP OfficeJet g55/g85/g95/k60/k80 | |
| HP OfficeJet H470/b/wbt/100 mobile/150 mobile | |
| HP OfficeJet 500/590/625/635 | |
| HP OfficeJet 700/710/725 | |
| HP OfficeJet 4105/4110 | |
| HP OfficeJet 4212/4215/4219/4252/4255/6110 | |
| HP OfficeJet 4315/4355 | |
| HP OfficeJet 4500 G510 a/g/n | |
| HP OfficeJet 5110/v30/v40/v45/HP PSC 750/950/Fax 1230 | |
| HP OfficeJet 5505/5510/5515 | |
| HP OfficeJet 5605 | |
| HP OfficeJet 5607 | |
| HP OfficeJet 5610 | |
| HP OfficeJet 5615 | |
| HP OfficeJet 6213 | |
| HP OfficeJet 6313 | |
| HP OfficeJet 7213/7313/7413 | |
| HP OfficeJet 9110/9120/9130 | |
| HP OfficeJet K7103 | |
| HP OfficeJet J3680 | |
| HP OfficeJet J4580/J4660/J4680 | |

| HP InkJet Printers | HP 178 Series Photosmart Photo Value Pack 10 × 15 cm/50 sheets[1] |
|---|---|
| | T9D89HE |
| HP OfficeJet J5520 | |
| HP OfficeJet J5783/J6413 | |
| HP OfficeJet Pro 1150c | |
| HP OfficeJet Pro 1170c/1175c | |
| HP OfficeJet Pro 251dw, 276dw | |
| HP OfficeJet Pro 6230 ePrinter, 6830 e-Ai0 | |
| HP OfficeJet 6000/6500/7000 series | |
| HP OfficeJet 6500A/7500A wf | |
| HP OfficeJet 6500A Plus | |
| HP OfficeJet 6700 Premium e-All-In-One | |
| HP OfficeJet 7100 WF ePrinter/7510 WF/7610 WF e-Ai0/7612 WF | |
| HP OfficeJet Pro 8210/8218 | |
| HP OfficeJet Pro 8710/8715/8718/8719 | |
| HP OfficeJet Pro 8720/8725/8730/8740 | |
| HP OfficeJet Pro 7740 WF | |
| HP OfficeJet Pro 8000/8500 series/8500A/8500A Plus | |
| HP OfficeJet Pro K550/K5400/K8600 | |
| HP OfficeJet Pro L7480/L7580/L7590/L7680/L7780 | |
| HP OfficeJet Pro K850 series | |
| HP OfficeJet Pro 8600 e-Ai0/8600 Plus e-Ai0/8610/8615/8620 | |
| HP OfficeJet Pro 8100 e-Printer (N811a) | |
| HP OfficeJet Pro X451 dw, X551 dw, X476 dw MFP, X576 dw MFP | |
| HP PageWide Pro 352dn/377dn | |
| HP PageWide Pro 452dw/477dw | |
| HP PSC 500 | |
| HP PSC 1100/1200 series | |
| HP PSC 1205 | |
| HP PSC 1210/1213/1215/1217/1219 | |
| HP PSC 1310 | |
| HP PSC 1311/1312/1315/1315s/1317 | |
| HP PSC 1340/1350/1355 | |
| HP PSC 1402/1410/1415/1417 | |
| HP PSC 1513/1513s | |
| HP PSC 1613 | |
| HP PSC 2105/2108/2110/2115/2171/2175/2179/2210 | |
| HP PSC 2353 | |
| HP PSC 2410/2510 | |
| HP Fax 1220 | |
| HP Fax 3180 | |
| **HP Photosmart** | |
| HP Photosmart 100/130/230 | |
| HP Photosmart 145/245 | |
| HP Photosmart 325/335/375/385/428/475 | |
| HP Photosmart A432/A433/A440/A441/A444/A516/A526/A532/A612/A646 | |
| HP Photosmart A310/A314/A320/A436/A618/A626/A636/A717/A826 | |
| HP Photosmart 1000/1100/1115/1215/1218/1315 | |
| HP Photosmart 2573 | |
| HP Photosmart 2613/2713 | |
| HP Photosmart 3213/3313/D7163/D7263/D7363/D7463 | |
| HP Photosmart C3183 | |
| HP Photosmart C4183 | |
| HP Photosmart C4273/C4283/C4343/C4383/C4473/C4483/C4583 | |
| HP Photosmart C4683/C4783 | |
| HP Photosmart C5183/C6183/C6283/C7183/C7283/C8183 | |
| HP Photosmart C5283 | |
| HP Photosmart D5063 | |
| HP Photosmart D5163 | |
| HP Photosmart D5363 | |
| HP Photosmart B8553/C5383/C6383/D5463 | • |
| HP Photosmart 7150/7260/7345/7350/7450/7459/7550/7655 | |
| HP Photosmart 7660/7755/7760/7762/7960/7690gp | |
| HP Photosmart 8053 | |
| HP Photosmart 8153/8453 | |
| HP Photosmart 8253 | |
| HP Photosmart 8753 | |
| HP Photosmart Pro B8353 | |
| HP Photosmart Pro B9180/B8850 | |
| HP Photosmart B010b/B109c, B110a | • |
| HP Photosmart Plus B209b, B210b | • |
| HP Photosmart Premium C309h, C310b | • |
| HP Photosmart Premium Fax C309c, C410c | • |
| HP Photosmart Wireless B109g, B109r, B110 d/e | • |
| HP Photosmart 5510/5515/6510 e-Ai0 printers | • |
| HP Photosmart 7510 e-Ai0 | • |
| **HP ENVY** | |
| HP ENVY 110 e-Ai0 | |

[1] Obsolete since 31st of October 2016. Only available in Russia.
[6] DeskJet Ink Advantage printers available in new Zone C (CISMEA countries plus selected CEE/MEMA countries that so far were part of EU+).

hp.com/go/learnaboutsupplies

© Copyright 2017 HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

4AA6-6064EEE, December 2017