Appliance status: R Valid from: 14. 09. 2018 Last modification: 11. 08. 2021 03:57:09

PRODUCT FICHE



Microwave oven with grill
733241
MO20S4W

USP :

Control type	Electronic control
Easy use	Allowing rapid heating of food activated by a single touch, the SmartStart function will prove particularly handy when you just can't wait for your warm meal.
Technology of producing microwaves	Standard technology (HTV)
Type of microwave distribution	Rotating plate
Input type	TouchControl
Type of display	LED display
Smart Control	SmartControl
Display can be switched off	In case of prolonged absence or if you just wish to be more eco-friendly, you can activate the power-saving mode in which the display is turned off. You can save up to 40 % on standby energy.
AUTO menu	The SoftMelt automatic program gently melts chocolate or butter at a constant temperature, thereby creating perfect conditions for melting, without burning.
Preinstalled programmes	11
Speed and auto defrost (by time and weight)	✔
Function Smart display	Elegant and clearly laid out LED display allows you to monitor the cooking or heating progress in the microwave oven. The countdown timer provides up-to-date information on how much longer the cooking process will take and which heating elements are in use.
Start preset	This convenient function allows setting the time when you wish the microwave oven operation to start. Thus, freshly cooked food will be ready just when you want it.
Multi level cooking	You can cook in several stages by manually programming a few steps of the cooking process. For example, in step 1 you may opt for more microwaves than grill, in step 2 the other way around, and you may set step 3 to achieve a final crust with just grilling. When you activate the StepBake mode, the microwave oven automatically changes the steps so you don't have to do it manually.
Time display	All Gorenje microwave ovens allow setting the operating time – from 30 to 60 minutes, depending on the model. The timer display clearly indicates the time remaining until the end of the cooking process.
ChildLock	The oven can be simply locked to prevent inadvertent use.
Door safety bolt	Safety switch makes sure the use of the microwave oven is perfectly safe. It automatically stops the program progress if the door is opened during operation.
AquaClean function	Oven interior can be cleaned by filling a high -temperature-resistant glass or clay cup with tap water, placing it in the oven, and activating the AquaClean program. The resulting steam will soften any dirt on the oven walls. At the end of the program, simply clean the oven with a damp cloth.

Basic information :

Brand	Gorenje
Product name / Family	Microwave oven with grill
Commercial code	MO20S4W
Internal article number	733241
EAN code	3838782176562
Construction type	Free-standing
Type of micro-wave oven	MW+Grill function
Cavity capacity	20 l

Maximum micro-wave power	800 W
Grill power	1000 W
Door opening	Button
Color / Material front	N/A
Front screen material	Yes
Connection Rating	1280 W
Current	8 A
Voltage	220-240 V
Frequency	50 Hz
Length of electrical supply cord	95 cm
Plug type	Euro/schuko
Net weight	11,5 Kg
Gross weight	13,3 Kg
Product group	Microwave oven with grill
Main colour of product	N/A
Installation type	N/A
Height of the product	257 mm
Width of the product	451 mm
Depth of the product	343 mm
Cavity height	212 mm
Cavity width	300 mm
Cavity depth	296 mm
Height of the packed product	294 mm
Width of the packed product	482 mm
Depth of the packed product	386 mm

Features :

Additional cooking method Grill	Yes
Additional cooking method Fan cooking	No
Additional cooking method Conventional	Yes
Type of combination	Microwaves+grill
Type of grill	Quarc
Type of control	Electronic
Clock	Yes
Number of power levels	5
Turntable	Yes
Turntable diameter	270 mm
Cavity material	Painted
Included accessories	N/A
Automatic programmes	Yes
Integrated Cleaning system	N/A
Interior light	Yes
Short description of the product	M20XYZ - MO20S4W - SUPERIOR LINE
Timer	No
Update function	No