Lenovo

V540-24IWL AIO

Setup Guide



Initial Setup











* 

* 

* For selected models








Lenovo



Overview



* 1. Integrated camera shield
* 2. Integrated microphones
* 3. Integrated camera activity indicator
* 4. Integrated camera (2)
* 5. Optical drive eject/close button
* 6. Optical drive activity indicator
7. Power button
* 8. Internal speakers (2)
9. Headset connector
* 10. SD-card slot
11. USB 3.1 connector Gen 2
12. USB 2.0 connectors (2)
13. HDMI™ 1.4 in connector
14. Power adapter connector
15. Ethernet connector
16. HDMI 1.4 out connector
17. USB 2.0 connectors (2)
18. USB 3.1 connector Gen 2
19. Security-lock slot

* For selected models

Read the statement on USB transfer rate in the *User Guide*. Refer to the *Safety and Warranty Guide* for accessing the *User Guide*.

Additional information

European Union — compliance with the Radio Equipment Directive

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type Lenovo V540-24IWL AIO is in compliance with Directive 2014/53/EU.

The full text of the system EU declaration of conformity and the EU wireless module declarations are available at the following Internet addresses:

- For desktop and all-in-one computers: https://www.lenovo.com/eu-doc-desktops
- For workstations: https://www.lenovo.com/eu-doc-workstations

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

Technology	Frequency band [MHz]	Maximum transmit power
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

E-manual

Second Edition (August 2019)

© Copyright Lenovo 2019.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration “GSA” contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce | Reuse | Recycle