User Guide

MARS GAMING
GAMERS UNIVERSE

MHBTX Audio combo



How to connect the Bluetooth speaker

To connect the Bluetooth speaker to your preferred device, follow these steps:

1. Turn your speaker on and select Bluetooth mode.LED indicator will light on blue.
2. Search the speaker in the list of available devices from your own device.
3. Play your media files.

Manage Calls & Music

**Features may vary depending on the device*



Features

- **ON/OFF:** Hold the ▶ / ⏸ button
- **Call Function:** Press the ▶ / ⏸ button to pick or hang the call
- **Next/Previous song:** Press ⏮ / ⏭
- **Increase/Decrease volume:** Hold + or -

· The LED indicator doesn't light on Bluetooth Mode:
1. Check if the battery is low and recharge it
2. Restart your device

Be aware of these indications while using your MHBTX devices:

- Try not to stay more than 5 meters away from your Bluetooth device.
- If the device isn't paired in a few minutes, it will go off automatically.
- Connect your over-hear headset with jack/jack cable if you don't want to use its battery.
- To improve radio signal, connect the power cable to the speaker.
- The LED indicator will light different colors according to the state of your device:

  - **Red (static):** Charging battery
  - **Red (blink):** Low battery
  - **Blue + red (blink):** Pairing
  - **Blue (blink):** Pairing with the device

- When pairing your devices, follow these references to recognize every MHBTX unit in the Bluetooth list:

  - **MHBTX1:** Over-ear headset
  - **MHBTX2:** In-ear headphones
  - **MHBTX3:** Speaker

WWW.MARSGAMING.EU

ES manual en español en **www.marsgaming.eu** / **IT** manuale in italiano su **www.marsgaming.eu** / **PT** Manual português em **www.marsgaming.eu** / **FR** manuel en français sur **www.marsgaming.eu** / **DE** handbuch in deutsch in **www.marsgaming.eu** / **PL** instrukcja obsługi w języku polskim **www.marsgaming.eu** / **RU** Руководство по эксплуатации на русском языке по адресу **www.marsgaming.eu**

- **Bluetooth mode:** The LED will blink in blue when the speaker is on Bluetooth mode and will change to static when connected to another device.
- **Battery charge:** The LED will light in red while charging the battery and will stay red until fully charged
- **MicroSD card:** Insert the microSD card with your music to automati cally play it.
- **Radio Mode:** Select P3 mode. Hold down the control wheel in Play/Pause position during 2 seconds to activate your speaker's Radio Mode.
- **Automatic tuning:** Press the control wheel in Play/Pause position so it starts searching and saving tunes. Please wait until the process is finished.

FAQ

· My Bluetooth device doesn't pair correctly:
1. Check if the speaker is in Bluetooth Mode
2. Check if the speaker isn't paired to another device
3. Check if there are too many Bluetooth devices around you that may interfere with the connection
4. Try to restart the Bluetooth of your tablet or cellphone and try to connect again

· My voice doesn't sound/ sounds distorted:
1. Check the volume of your device and your speaker, and adjust it properly
2. Check if the battery is low

· Music breaks during playing:
1. Check if the device is in optimal range for connection
2. Check if there are obstacles between your devices