Lenovo


IdeaCentre T540-15AMA G


Setup Guide





Initial Setup






* 


* 

* 

* For selected models


1
2
3
Lenovo

Overview



1. Power button
2. 7 in 1 card reader slot (optional)
3. Microphone connector
4. Headset connector
5. USB 3.1 connectors Gen 2 (2)
6. USB 3.1 connectors Gen 1 (2)
7. Audio line-in connector
8. Audio line-out connector
9. Microphone connector
10. VGA-out connector
11. HDMI™ out connector
12. USB 3.1 connectors Gen 1 (2)
13. USB 2.0 connectors (2)
14. Ethernet connector
15. Power cord connector

Additional information

European Union — compliance with the Radio Equipment Directive

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type IdeaCentre T540-15AMA G is in compliance with Directive 2014/53/EU.

The full text of the system EU declaration of conformity and the EU wireless module declarations are available at the following Internet addresses:

- For desktop and all-in-one computers: https://www.lenovo.com/eu-doc-desktops
- For workstations: https://www.lenovo.com/eu-doc-workstations

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

Technology	Frequency band [MHz]	Maximum transmit power
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

First Edition (September 2019)

© Copyright Lenovo 2019.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration “GSA” contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce I Reuse I Recycle

