Philips
Cleaning kit

• CD/DVD

SVC2235





CD/DVD disc and player cleaning kit

Regular cleaning of your CDs, DVDs and players prolongs the life of your discs and protects your players. Regular cleaning of your discs and player's lens also ensures top performance from your equipment. Now get everything in one package.

Safely clean your CD and DVD discs
- Special cleaning fluid to safely clean discs
- Dry cleaning wipes
- Safe and easy radial cleaning action
- Microfibre cleaning pad

Maintain original sound and video quality
- Safe dry brush cleaning system

Maintain original sound quality
- Audio system check for correct setting

Easy to use
- Voice instructions in 14 languages

PHILIPS

Cleaning kit
CD/DVD

SVC2235/10

Specifications

Accessories
- User Manual: 15 languages

Technical specifications
- Contents: Cleaning Fluid, 30 ml

Storage Media
- Supported formats: CD-Audio, CD-Rewritable, CD-ROM, DVD-ROM, DVD/R, DVD/RW

Packaging dimensions
- Type of shelf placement: Soother
- Packaging dimensions (W x H x D): 18.4 x 22.23 x 6.55 cm
- Net weight: 0.2331 kg
- Gross weight: 0.364 kg
- Tare weight: 0.1309 kg
- EAN: 87 12581 56464 3
- Number of products included: 4
- Packaging type: Soother

Outer Carton
- Outer carton (L x W x H): 39.8 x 24.1 x 20.3 cm
- Net weight: 1.3986 kg
- Gross weight: 2.65 kg
- Tare weight: 1.2514 kg
- EAN: 87 12581 57362 1
- Number of consumer packages: 6

Highlights

Special cleaning fluid
This cleaning fluid is specially formulated to gently clean away dirt and dust from your discs. Works with the non-abrasive cloth.

Dry cleaning wipes
These lint-free, non-abrasive wipes gently work to safely remove dust, dirt and debris from discs.

Radial cleaning action
Clean and protect your discs with this safe and easy radial cleaning action that clears discs of dirt, dust and debris.

Microfibre cleaning pad
This cleaning pad is made of special microfibre material. It works in concert with anti-static cleaning fluid to ensure that your discs are cleaned safely and remain free from dust and dirt.

Dry brush system
The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD player's laser lens, leaving it clean and performing optimally.

Audio system check
The audio system check determines whether the speakers are properly adjusted.

Voice instructions
The voice instructions on this easy-to-use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.

Issue date 2013-05-23
Version: 1.0.8
12 NC: 8670 000 68319
EAN: 87 12581 56464 3

© 2013 Koninklijke Philips N.V.
All Rights reserved.
Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com