Quick installation guide IB-CA100

Hot shoe clamp for external storage

Schnellinstallationsanleitung IB-CA100

Blitzschuh Klemme für externen Speicher



D

ICY BOX®

Sicherheitshinweise IB-CA100

Zur Vermeidung körperlicher Schäden, sowie von Sach-, Geräteschäden und Datenverlust beachten Sie bitte folgende Hinweise:

Warnstufen
Signalwort und Sicherheitszeichen kennzeichnen die Warnstufe und geben einen sofortigen Hinweis auf Wahrscheinlichkeit, Art und Schwere der Folgen, wenn die Maßnahmen zur Vermeidung der Gefahr nicht befolgt werden.

⚠ **GEFAHR**	warnt vor einer **unmittelbar** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **wird**.
⚠ **WARNUNG**	warnt vor einer **möglicherweise** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **kann**.
⚠ **VORSICHT**	warnt vor einer **möglicherweise** gefährlichen Situation, die zu leichten Verletzungen führen **kann**.
ACHTUNG	warnt vor einer **möglichen** Situation, die zu Sach- und Umweltschäden führen und den Betriebsablauf stören **kann**.

D

ICY BOX®

Sicherheitshinweise IB-CA100

1. Gefahren durch elektrische Spannung

WARNUNG

Kontakt mit elektrisch leitenden Teilen

Lebensgefahr durch Stromschlag

- vor Benutzung Betriebsanleitung lesen
- vor Arbeiten am Gerät, Spannungsfreiheit sicherstellen
- Kontaktschutzblenden nicht entfernen
- Kontakt mit Spannungsführenden Komponenten vermeiden.
- Steckkontakte nicht mit spitzen und metallischen Gegenständen berühren
- Verwendung nur in dafür vorgesehenen Umgebungen
- Gerät ausschließlich mit Typenschildkonformen Netzteil betreiben!
- Gerät/Netzteil fern von Feuchtigkeit, Flüssigkeit, Dampf und Staub halten
- Eigenständige Modifikationen sind unzulässig
- Gerät nicht während eines Gewitters anschließen
- Geben Sie Ihr Gerät im Reparaturfall in den Fachhandel

2. Gefahren während Montage (wenn vorgesehen)

VORSICHT

Scharfkantige Bauteile

Finger- oder Handverletzungen bei Zusammenbau (wenn vorgesehen) möglich

- vor Montage, Betriebsanleitung lesen
- Kontakt mit scharfen Kanten oder spitzen Bauteilen vermeiden
- Bauteile nicht mit Gewalt zusammensetzen
- geeignetes Werkzeug verwenden
- nur gegebenenfalls mitgeliefertes Zubehör und Werkzeug verwenden

D

ICY BOX®

Sicherheitshinweise IB-CA100

3. Gefahren durch Wärmeentwicklung

ACHTUNG

Mangelhafte Belüftung des Geräts/Netzteils
Überhitzung und Ausfall des Geräts/Netzteils

- externe Erwärmung vermeiden und Luftaustausch zulassen
- Lüfter-Auslass und passive Kühlkörper freihalten
- direkte Sonneneinstrahlung auf Gerät/Netzteil vermeiden
- ausreichend Umgebungsluft für Gerät/Netzteil sicherstellen
- keine Gegenstände auf dem Gerät/Netzteil abstellen

4. Gefahren durch Kleinstteile und Verpackung

WARNUNG

Erstickungsgefahr
Lebensgefahr durch Ersticken oder Verschlucken

- Kleinteile, Zubehör für Kinder unzugänglich verwahren
- Plastiktüten und Verpackung für Kinder unzugänglich verwahren/entsorgen
- Kleinteile und Verpackungen nicht in Kinderhände geben

5. Möglicher Datenverlust

ACHTUNG

Datenverlust bei Inbetriebnahme
Unwiederbringlicher Datenverlust möglich

- Unbedingt Hinweise in der Bedienungsanleitung/Schnellinstallationsanleitung beachten
- Produkt nur verwenden, wenn Spezifikationen erfüllt sind
- Datensicherung vor Inbetriebnahme durchführen
- Datensicherung vor Anschluss neuer Hardware durchführen
- dem Produkt beiliegendes Zubehör verwenden

D

ICY BOX®

Sicherheitshinweise IB-CA100

6. Reinigung des Gerätes

ACHTUNG


Schädigende Reinigungsmittel
Kratzer, Farbveränderungen, Feuchteschäden oder Kurzschluss am Gerät

- vor Reinigung, das Gerät außer Betrieb nehmen
- aggressive bzw. scharfe Reinigungs- und Lösungsmittel sind ungeeignet
- nach der Reinigung sicherstellen, dass keine Restfeuchtigkeit vorhanden ist
- Reinigung der Geräte am besten mit trockenem Antistatiktuch durchführen

7. Entsorgung des Gerätes

ACHTUNG

Umweltverschmutzung, Wiederverwertung nicht möglich
Mögliche Umweltbelastung durch Bestandteile, Recyclingkreislauf unterbrochen



Dieses auf dem Produkt und der Verpackung angebrachte Symbol zeigt an, dass dieses Produkt nicht mit dem Hausmüll entsorgt werden darf. In Übereinstimmung mit der Richtlinie über Elektro- und Elektronik-Altgeräte (**WEEE**) darf dieses Elektrogerät und ggf. enthaltene Batterien nicht im normalen Hausmüll oder dem **Gelben Sack** entsorgt werden. Wenn Sie dieses Produkt und ggf. enthaltene Batterien entsorgen möchten, bringen Sie diese bitte zur Verkaufsstelle zurück oder zum Recycling-Sammelpunkt Ihrer Gemeinde.

Bei Fragen kontaktieren Sie gerne unseren Support unter
support@raidsonic.de oder besuchen Sie unsere Internetseite **www.raidsonic.de**.

E

ICY BOX®

Safety instructions IB-CA100

Please read carefully the following information to prevent injuries, damage to material and device as well as data loss:

Warning levels

Signal words and safety codes indicate the warning level and provide immediate information in terms of the probability of occurrence as well as the type and severity of the consequences if the measures to prevent hazards are not complied with.

DANGER	Warns of a **directly** hazardous situation causing **death or serious injury**.
WARNING	Warns of a **potentially** hazardous situation that **may** cause death or serious injury.
CAUTION	Warns of a **potentially** hazardous situation that **may** cause minor injury.
IMPORTANT	Warns of a **potential** situation that **may** cause material or environmental damage and disrupt operative processes.

E

ICY BOX®

Safety instructions IB-CA100

1. Risk of electrical shock

WARNING

Contact with parts conducting electricity
Risk of death by electrical shock

- Read the operating instructions prior to use
- Make sure the device has been de-energised prior to working on it
- Do not remove contact protection panels
- Avoid contact with conducting parts
- Do not bring plug contacts in contact with pointed and metal objects
- Use in intended environments only
- Operate the device using a power unit meeting the specifications of the type plate only!
- Keep the device/power unit away from humidity, liquid, vapour and dust
- Do not modify the device
- Do not connect the device during thunderstorms
- Approach specialist retailers if you require repairs

2. Hazards during assembly (if intended)

CAUTION

Sharp components
Potential injuries to fingers or hands during assembly (if intended)

- Read the operating instructions prior to assembly
- Avoid coming into contact with sharp edges or pointed components
- Do not force components together
- Use suitable tools
- Use potentially enclosed accessories and tools only

E

ICY BOX®

Safety instructions IB-CA100

3. Hazards caused by a development of heat

IMPORTANT

Insufficient device/power unit ventilation

Overheating and failure of the device/power unit

- Prevent externally heating up components and ensure an exchange of air
- Do not cover the fan outlet and passive cooling elements
- Avoid direct sunlight on the device/power unit
- Guarantee sufficient ambient air for the device/power unit
- Do not place objects on the device/power unit

4. Hazards caused by very small parts and packaging

⚠ WARNING

Risk of suffocation

Risk of death by suffocation or swallowing

- Keep small parts and accessories away from children
- Store/dispose of plastic bags and packaging in an area that is inaccessible to children
- Do not hand over small parts and packaging to children

5. Potential data loss

IMPORTANT

Data lost during commissioning

Potentially irreversible data loss

- Always comply with the information in the operating instructions/quick installation guide
- Exclusively use the product once the specifications have been met
- Back up data prior to commissioning
- Back up data prior to connecting new hardware
- Use accessories enclosed with the product

E

ICY BOX®

Safety instructions IB-CA100

6. Cleaning the device

IMPORTANT


Harmful cleaning agents
Scratches, discolouration, damage caused by moisture or short circuit in the device

- Disconnect the device prior to cleaning
- Aggressive or intense cleaning agents and solvents are unsuitable
- Make sure there is no residual moisture after cleaning
- We recommend cleaning devices using a dry, anti-static cloth

7. Disposing of the device

IMPORTANT

Environmental pollution, unsuitable for recycling
Potential environmental pollution caused by components, recycling circle interrupted



This icon on product and packaging indicates that this product must not be disposed of as part of domestic waste. In compliance with the Waste Electrical and Electronic Equipment Directive (**WEEE**) this electrical device and potentially included batteries must not be disposed of in conventional, domestic waste or **recycling waste**. If you would like to dispose of this product and potentially included batteries, please return it to the retailer or your local waste disposal and recycling point.


If you have any questions, please do not hesitate to contact our support at **support@raidsonic.de** or visit our website at **www.raidsonic.de**.

E

ICY BOX®

Quick installation guide IB-CA100

Overview




1	2x fastening screw (M3)
2	1.4“ tripod thread
3	2x Non-slip rubber pad
4	Counter screw

E

ICY BOX®

Quick installation guide IB-CA100



For the device from 9mm to 16mm thickness.

Package content:

1x IB-CA100, 1x quick installation guide

Key features:

- Made of high-grade aluminum
- Ideal for mounting external memory
- Suitable for all common camera hot shoe mounts
- Clamping width of 9 -16 mm
- Rubber pads to protect the memory


E

ICY BOX®

Quick installation guide IB-CA100

Installation:

1. Unscrew the two fastening screws by hand or screwdriver or coin so that the upper part of the clamp is loosened.
   Note: Turn counterclockwise
2. Place your device of 9 to 16 mm thickness in the clamp and put the upper part of the clamp back on.
3. Tighten the two fastening screws well so that your device has a secure hold. Use a screwdriver or coin if necessary.




D

ICY BOX®

Schnellinstallationsanleitung IB-CA100

Übersicht




1	2x Befestigungsschraube (M3)
2	1,4“ Stativgewinde
3	2x Antirutsch Gummieinlage
4	Blitzschuh Halterung

D

ICY BOX®

Schnellinstallationsanleitung IB-CA100



Für Geräte von 9mm bis 16mm Dicke.

Verpackungsinhalt:

1x IB-CA100, 1x Schnellinstallationsanleitung

Hauptmerkmale:

- Aus hochwertigem Aluminium
- Ideal zur Befestigung von externem Speicher
- Passend für alle gängigen Kamera Blitzschuh Halterungen
- Klemmweite von 9 – 16 mm
- Gummieinlagen zum Schutz des Speichers


D


ICY BOX®

Schnellinstallationsanleitung IB-CA100


Installation:

1. Schrauben Sie die beiden Befestigungsschrauben von Hand oder mittels Schraubendreher oder Münze auf, sodass sich der obere Teil der Klemme löst.
   Hinweis: Gegen den Uhrzeigersinn drehen
2. Legen Sie Ihr Gerät von 9 bis 16 mm Dicke in die Klemme und legen Sie den oberen Teil der Klemme wieder auf.
3. Ziehen Sie die beiden Befestigungsschrauben gut an, sodass Ihr Gerät einen sicheren Halt hat. Nehmen Sie, wenn nötig, auch hier einen Schraubendreher oder Münze zu Hilfe.





ICY BOX®



© Copyright 2020 by RaidSonic Technology GmbH. All Rights Reserved.

The information contained in this manual is believed to be accurate and reliable. RaidSonic Technology GmbH assumes no responsibility for any errors contained in this manual. RaidSonic Technology GmbH reserves the right to make changes in the specifications and/or design of the above mentioned product without prior notice. The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only. RaidSonic Technology GmbH assumes no responsibility for any differences between the product mentioned in this manual and the product you may have.