PHILIPS



Philips Pure Essentials Collection Toaster

HD2686/30

- 2 slot
- 3 function electronic
- White
- Extra-long slot

Have it your way, exactly your way

Toaster for different types of bread

- Extra-wide and extra-deep slot(s) to fit your bread
- Evenly toasts thick or thin slices
- Bun warming rack to warm buns and croissants
- Extra-long slots to fit all kinds of bread
- Defrost and toast frozen bread at any browning level
- Reheat setting warms or further browns just toasted bread
- Cancel button stops toasting at any time
- High lift feature to safely take out small pieces of bread
- The outside of the toaster stays cool and safe to touch
- Removable crumb tray for easy cleaning

Highlights

Extra-wide and extra-deep slot(s)

Extra-wide and extra-deep slot(s) to fit your bread.

Variable-width bread slots



Evenly toasts thick or thin slices.

Bun warming rack



Bun warming rack to warm buns and croissants.

Extra-long slots

Extra-long slots to fit all kinds of bread.

Frozen bread function

Reheat setting



Cancel button

High lift feature



High lift feature to safely take out small pieces of bread.

Cool wall exterior



Specifications

Design specifications

: Housing: metal/plastic (PC/ABS), chrome plated top
Colour(s): White, metal and red

General specifications

Automatic safety shut-off: Yes
Multiple toast settings: 8

Technical specifications

Slot size (L x W x H): 152 x 30 x 130 mm
Cord length: 0.85 m
Power: 1500 W
Voltage: 220-240 V
Frequency: 50/60 Hz

Publication Date
2025-09-06
Version: 1.1.1
www.phillips.com

2025 © Versuni Holding B.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.